
QUINTAL HOME

IMPROVE YOUR LIFE



QUINTAL HOME
IMPROVE YOUR LIFE

SMALL BUTTON SERIES

D1 SERIES	**P03/04**	**D7** SERIES	**P13/14**
D2 SERIES	**P05**	**D8** SERIES	**P15/16**
D3 SERIES	**P06**	**D9** SERIES	**P17/18**
D4 SERIES	**P07/08**		
D5 SERIES	**P09/10**		
D6 SERIES	**P11/12**		

ULTRA-THIN SERIES

W1 SERIES	**P23/28**	**W6** SERIES	**P45/48**
W1 Dermatoglyph	**P29/32**	**W8** SERIES	**P49/52**
W2/W3/W5 SERIES	**P33/36**	**W9** SERIES	**P53/56**
W4 SERIES	**P37/40**	**W10** SERIES	**P57/60**
W6 GLass	**P41/44**		

BRITISH TYPE SERIES

C1 SERIES	**P63/66**	**C9** SERIES	**P85/88**
C1 Acrylic	**P67/70**	**M3** SERIES	**P89/92**
C2/C3 SERIES	**P71/74**	**Q2/Q4** SERIES	**P93/96**
C7 SERIES	**P75/78**		
C8 SERIES	**P79/84**		

QUINTAL HOME
IMPROVE YOUR LIFE

SMALL BUTTON SERIES







D1
SERIES

Exquisite shape and gengerous appearance.
Endow white wall switch with aethetic significance

D1

PC Small Button design pure white/painting
Iron bracket +PC bottom+Copper inside part

QUINTAL HOME
IMPROVE YOUR LIFE



D1-001
1gang 1way switch

D1-002
1gang 2way switch



D1-003
2gang 1way switch

D1-004
2gang 2way switch



D1-005
3gang 1way switch

D1-006
3gang 2way switch



D1-007
4gang1way switch

D1-008
4gang 2way switch



D1-009
1 switch + 1 socket



D1-010
2 switch + 2 socket



D1-011
20A switch w/without neon



D1-012
45A switch w/without neon



D1-013
13A switch socket
w/without neon



D1-014
13A MF switch socket
w/without neon



D1-015
15A switch socket
w/without neon



D1-016
1 gang 5 Pin
w/without neon



D1-017
1 gang 8Pin
w/without neon



D1-018
Waterproof Bell Push



D1-019
Dimmer (small)



D1-020
Switched Dimmer (small)



D1-021
TV



D1-022
satellite



D1-023
TEL Socket

D1-024
Computer Socket



D1-025
Double TEL Socket

D1-026
Double Computer Socket



D1-027
TEL + Computer Socket



D1-028
TV + Computer Socket



D1-029
Computer+Satellite

D1-030
TEL+Satellite

D1-031
Blank plate(86*86)

D1-032
Blank plate(86*146)

D2

PC Small Button design pure white/painting
Iron bracket +PC bottom+Copper inside part



D2-001
1gang 1way switch

D2-002
1gang 2way switch



D2-003
2gang 1way switch

D2-004
2gang 2way switch



D2-005
3gang 1way switch

D2-006
3gang 2way switch



D2-007
4gang1way switch

D2-008
4gang 2way switch



D2-009
1 switch + 1 socket



D2-010
2 switch + 2 socket



D2-011
20A switch w/without neon



D2-012
45A switch w/without neon



D2-013
13A switch socket
w/without neon



D2-014
13A MF switch socket
w/without neon



D2-015
15A switch socket
w/without neon



D2-016
1 gang 5 Pin
w/without neon



D2-017
1 gang 8Pin
w/without neon



D2-018
Waterproof Bell Push



D2-019
Dimmer (small)



D2-020
Switched Dimmer (small)



D2-021
TV



D2-022
satellite



D2-023
TEL Socket

D2-024
Computer Socket



D2-025
Double TEL Socket

D2-026
Double Computer Socket



D2-027
TEL + Computer Socket




D2-028
TV + Computer Socket



D2-029
Computer+Satellite

D2-030
TEL+Satellite



D2-031
Blank plate(86*86)



D2-032
Blank plate(86*146)

D3

PC Small Button design pure white/painting+electric plating
Iron bracket +PC bottom+Copper inside part



D3-001
1gang 1way switch

D3-002
1gang 2way switch



D3-003
2gang 1way switch

D3-004
2gang 2way switch



D3-005
3gang 1way switch

D3-006
3gang 2way switch



D3-007
4gang1way switch

D3-008
4gang 2way switch



D3-009
1 switch + 1 socket



D3-010
2 switch + 2 socket



D3-011
20A switch w/without neon



D3-012
45A switch w/without neon



D3-013
13A switch socket
w/without neon



D3-014
13A MF switch socket
w/without neon



D3-015
15A switch socket
w/without neon



D3-016
1 gang 5 Pin
w/without neon



D3-017
1 gang 8Pin
w/without neon



D3-018
Waterproof Bell Push



D3-019
Dimmer (small)

D3-020
Switched Dimmer (small)

D3-021
TV

D3-022
satellite

D3-023
TEL Socket

D3-024
Computer Socket

D3-025
Double TEL Socket

D3-026
Double Computer Socket

D3-027
TEL + Computer Socket

D3-028
TV + Computer Socket

D3-029
Computer+Satellite

D3-030
TEL+Satellite

D3-031
Blank plate(86*86)

D3-032
Blank plate(86*146)



D4
SERIES

D4

PC Small Button design pure white/painting+electric plating
Iron bracket +PC bottom+Copper inside part

QUINTAL HOME
IMPROVE YOUR LIFE



D4-001
1gang 1way switch

D4-002
1gang 2way switch



D4-003
2gang 1way switch

D4-004
2gang 2way switch



D4-005
3gang 1way switch

D4-006
3gang 2way switch



D4-007
4gang1way switch

D4-008
4gang 2way switch



D4-009
1 switch + 1 socket



D4-010
2 switch + 2 socket



D4-011
20A switch w/without neon



D4-012
45A switch w/without neon



D4-013
13A switch socket
w/without neon



D4-014
13A MF switch socket
w/without neon



D4-015
15A switch socket
w/without neon



D4-016
1 gang 5 Pin
w/without neon



D4-017
1 gang 8Pin
w/without neon



D4-018
Waterproof Bell Push



D4-019
Dimmer (small)



D4-020
Switched Dimmer (small)



D4-021
TV



D4-022
satellite



D4-023
TEL Socket

D4-024
Computer Socket



D4-025
Double TEL Socket

D4-026
Double Computer Socket



D4-027
TEL + Computer Socket



D4-028
TV + Computer Socket



D4-029
Computer+Satellite

D4-030
TEL+Satellite




D4-031
Blank plate(86*86)



D4-032
Blank plate(86*146)





D5

PC Small Button design pure white/painting+electric plating
Iron bracket +PC bottom+Copper inside part

QUINTAL HOME
IMPROVE YOUR LIFE



D5-001
1gang 1way switch

D5-002
1gang 2way switch



D5-003
2gang 1way switch

D5-004
2gang 2way switch



D5-005
3gang 1way switch

D5-006
3gang 2way switch



D5-007
4gang1way switch

D5-008
4gang 2way switch



D5-009
1 switch + 1 socket



D5-010
2 switch + 2 socket



D5-011
20A switch w/without neon



D5-012
45A switch w/without neon



D5-013
13A switch socket
w/without neon



D5-014
13A MF switch socket
w/without neon



D5-015
15A switch socket
w/without neon



D5-016
1 gang 5 Pin
w/without neon



D5-017
1 gang 8Pin
w/without neon



D5-018
Waterproof Bell Push



D5-019
Dimmer (small)



D5-020
Switched Dimmer (small)



D5-021
TV



D5-022
satellite



D5-023
TEL Socket

D5-024
Computer Socket



D5-025
Double TEL Socket

D5-026
Double Computer Socket



D5-027
TEL + Computer Socket



D5-028
TV + Computer Socket




D5-029
Computer+Satellite


D5-030
TEL+Satellite

D5-031
Blank plate(86*86)

D5-032
Blank plate(86*146)

D6
SERIES





Page 11

D6

PC Small Button design pure white/painting+electric plating
Iron bracket +PC bottom+Copper inside part

QUINTAL HOME
IMPROVE YOUR LIFE



D6-001
1gang 1way switch

D6-002
1gang 2way switch



D6-003
2gang 1way switch

D6-004
2gang 2way switch



D6-005
3gang 1way switch

D6-006
3gang 2way switch



D6-007
4gang1way switch

D6-008
4gang 2way switch



D6-009
1 switch + 1 socket



D6-010
2 switch + 2 socket



D6-011
20A switch w/without neon



D6-012
45A switch w/without neon



D6-013
13A switch socket
w/without neon



D6-014
13A MF switch socket
w/without neon



D6-015
15A switch socket
w/without neon



D6-016
1 gang 5 Pin
w/without neon



D6-017
1 gang 8Pin
w/without neon



D6-018
Waterproof Bell Push



D6-019
Dimmer (small)



D6-020
Switched Dimmer (small)



D6-021
TV



D6-022
satellite



D6-023
TEL Socket

D6-024
Computer Socket



D6-025
Double TEL Socket

D6-026
Double Computer Socket



D6-027
TEL + Computer Socket



D6-028
TV + Computer Socket




D6-029
Computer+Satellite

D6-030
TEL+Satellite



D6-031
Blank plate(86*86)




D6-032
Blank plate(86*146)

D7
SERIES









D7

PC Small Button design pure white/painting+electric plating
Iron bracket +PC bottom+Copper inside part

QUINTAL HOME
IMPROVE YOUR LIFE



D7-001
1gang 1way switch

D7-002
1gang 2way switch



D7-003
2gang 1way switch

D7-004
2gang 2way switch



D7-005
3gang 1way switch

D7-006
3gang 2way switch



D7-007
4gang1way switch

D7-008
4gang 2way switch



D7-009
1 switch + 1 socket



D7-010
2 switch + 2 socket



D7-011
20A switch w/without neon



D7-012
45A switch w/without neon



D7-013
13A switch socket
w/without neon



D7-014
13A MF switch socket
w/without neon



D7-015
15A switch socket
w/without neon



D7-016
1 gang 5 Pin
w/without neon



D7-017
1 gang 8Pin
w/without neon



D7-018
Waterproof Bell Push



D7-019
Dimmer (small)



D7-020
Switched Dimmer (small)



D7-021
TV



D7-022
satellite



D7-023
TEL Socket

D7-024
Computer Socket



D7-025
Double TEL Socket

D7-026
Double Computer Socket



D7-027
TEL + Computer Socket



D7-028
TV + Computer Socket



D7-029
Computer+Satellite

D7-030
TEL+Satellite



D7-031
Blank plate(86*86)



D7-032
Blank plate(86*146)







D8
SERIES

D8

PC Small Button design pure white/painting+electric plating
Iron bracket +PC bottom+Copper inside part

QUINTAL HOME
IMPROVE YOUR LIFE



D8-001
1gang 1way switch

D8-002
1gang 2way switch



D8-003
2gang 1way switch

D8-004
2gang 2way switch



D8-005
3gang 1way switch

D8-006
3gang 2way switch



D8-007
4gang1way switch

D8-008
4gang 2way switch



D8-009
1 switch + 1 socket



D8-010
2 switch + 2 socket



D8-011
20A switch w/without neon



D8-012
45A switch w/without neon



D8-013
13A switch socket
w/without neon



D8-014
13A MF switch socket
w/without neon



D8-015
15A switch socket
w/without neon



D8-016
1 gang 5 Pin
w/without neon



D8-017
1 gang 8Pin
w/without neon



D8-018
Waterproof Bell Push



D8-019
Dimmer (small)



D8-020
Switched Dimmer (small)



D8-021
TV



D8-022
satellite



D8-023
TEL Socket

D8-024
Computer Socket



D8-025
Double TEL Socket

D8-026
Double Computer Socket



D8-027
TEL + Computer Socket



D8-028
TV + Computer Socket



D8-029
Computer+Satellite

D8-030
TEL+Satellite




D8-031
Blank plate(86*86)



D8-032
Blank plate(86*146)



D9
SERIES











D9

PC Small Button design pure white/painting+electric plating
Iron bracket +PC bottom+Copper inside part

QUINTAL HOME
IMPROVE YOUR LIFE



D9-001
1gang 1way switch

D9-002
1gang 2way switch



D9-003
2gang 1way switch

D9-004
2gang 2way switch



D9-005
3gang 1way switch

D9-006
3gang 2way switch



D9-007
4gang1way switch

D9-008
4gang 2way switch



D9-009
1 switch + 1 socket



D9-010
2 switch + 2 socket



D9-011
20A switch w/without neon



D9-012
45A switch w/without neon



D9-013
13A switch socket
w/without neon



D9-014
13A MF switch socket
w/without neon



D9-015
15A switch socket
w/without neon



D9-016
1 gang 5 Pin
w/without neon



D9-017
1 gang 8Pin
w/without neon



D9-018
Waterproof Bell Push



D9-019
Dimmer (small)



D9-020
Switched Dimmer (small)



D9-021
TV



D9-022
satellite



D9-023
TEL Socket

D9-024
Computer Socket



D9-025
Double TEL Socket

D9-026
Double Computer Socket



D9-027
TEL + Computer Socket



D9-028
TV + Computer Socket



D9-029
Computer+Satellite

D9-030
TEL+Satellite



D9-031
Blank plate(86*86)



D9-032
Blank plate(86*146)

ULTRA-THIN
SERIES



ULTRA-THIN
SWITCH



6.5
Thin to 6.5mm

2°
Small swing angle

QUINTAL HOME
IMPROVE YOUR LIFE


Perfect Touch
Technical breakthrough

Breakthrough the traditional switch warping plate struture limitations


Break through the limitations of switch panel design
Explore the switching limits of traditional switches



Slimness beauty
Toughened organic glass panel switch



Slim like invisible
Most slimmest panel




Technical breakthrough
Comfortable touching feeling



W1
SERIES

QUINTAL HOME
IMPROVE YOUR LIFE





1.5°
Tiny amplitude of swing

2.5mm
Short button angle

6.5mm
Overall thickness

QUINTAL HOME
IMPROVE YOUR LIFE



W1
SERIES

Stainless steel or acrylic material, a variety of color free choice

W1

Stainless steel/Acrylic panel
Iron bracket +PC bottom+Copper inside part



W1-001
1gang 1way switch 16A

W1-002
1gang 2way switch 16A



W1-003
2gang 1way switch 16A

W1-004
2gang 2way switch 16A



W1-005
3gang 1way switch 16A

W1-006
3gang 2way switch 16A



W1-007
4gang1way switch 16A

W1-008
4gang 2way switch 16A



W1-009
doorbell switch



W1-010
1 gang 1way switch and 2 pin socket

W1-011
1 gang 2way switch and 2 pin socket



W1-012
1gang 1way switch and 2gang 2pin socket

W1-012-1
1gang 2way switch and 2gang 2pin socket



W1-013
2gang 1way switch and 2gang 2pin socket

W1-013-1
2gang 2way switch and 2gang 2pin socket



W1-014
13A socket



W1-015
5Pin MF socket



W1-016
MF switch socket
w/without neon



W1-017
15A switch socket
w/without neon



W1-018
13A switch socket
w/without neon



W1-019
5 pin MF switch socket
w/without neon



W1-020
MF switch socket
w/without neon



W1-021
15A switch socket
w/without neon



W1-022
13A switch socket
w/without neon



W1-023
5 pin MF switch socket
w/without neon



W1-024
MF switch socket+2USB
w/without neon



W1-025
MF switch socket+TypeA+C
w/without neon



W1-026
13A switch socket+2USB
w/without neon(single pole)

W1-027
13A switch socket+2USB
w/without neon(double pole)



W1-028
13A switch socket+TypeA+C
w/without neon(single pole)

W1-029
13A switch socket+TypeA+C
w/without neon(double pole)



W1-030
European socket



W1-031
French socket



W1-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



W1-033
45A switch with neon



W1-034
TV socket



W1-035
double TV socket

W1-036
computer socket



W1-037
tel socket



W1-038
satellite



W1-039
satellite+TV



W1-040
satellite+tel



W1-041
double satellite



W1-042
tv+tel socket

W1-043
TV+computer socket



W1-044
tel+computer socket

W1-045
double tel

W1-046
double computer socket



W1-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



W1-048
one gang switch+dimmer



W1-049
blank plate (3*3)



W1-050
blank plate(3*6)



W1-051
2* MF switch socket w/without neon

W1-052
2*MF switch socket+2USB
w/without neon

W1-053
2*MF switch socket +TypeA+C

W1-054
2*13A switch socket w/without neon
(single pole)

W1-055
2*13A switch socket w/without neon
(double pole)

W1-056
2*13A switch socket+2USB
w/without neon

W1-057
2*13A switch socket +TypeA+C


W1-058
45A switch with neon(3*6)

W1-059
cooker unit

W1
SERIES



Acrylic leather cover with high
quality electric plating,
The newest anti-conductive technology



1.5°
Tiny amplitude of swing

—


2.5mm
Short button angle

—

6.5mm
Overall thickness

W1

Acrylic leather panel
Iron bracket +PC bottom+Copper inside part




W1-001
1gang 1way switch 16A

W1-002
1gang 2way switch 16A



W1-003
2gang 1way switch 16A

W1-004
2gang 2way switch 16A



W1-005
3gang 1way switch 16A

W1-006
3gang 2way switch 16A



W1-007
4gang1way switch 16A

W1-008
4gang 2way switch 16A



W1-009
doorbell switch



W1-010
1 gang 1way switch and
2 pin socket

W1-011
1 gang 2way switch and 2
pin socket




W1-012
1gang 1way switch and
2gang 2pin socket

W1-012-1
1gang 2way switch and
2gang 2pin socket



W1-013
2gang 1way switch and
2gang 2pin socket

W1-013-1
2gang 2way switch and
2gang 2pin socket



W1-014
13A socket



W1-015
5Pin MF socket



W1-016
MF switch socket
w/without neon



W1-017
15A switch socket
w/without neon



W1-018
13A switch socket
w/without neon



W1-019
5 pin MF switch socket
w/without neon



W1-020
MF switch socket
w/without neon



W1-021
15A switch socket
w/without neon



W1-022
13A switch socket
w/without neon



W1-023
5 pin MF switch socket
w/without neon



W1-024
MF switch socket+2USB
w/without neon



W1-025
MF switch socket+TypeA+C
w/without neon



W1-026
13A switch socket+2USB
w/without neon(single pole)

W1-027
13A switch socket+2USB
w/without neon(double pole)



W1-028
13A switch socket+TypeA+C
w/without neon(single pole)

W1-029
13A switch socket+TypeA+C
w/without neon(double pole)



W1-030
European socket



W1-031
French socket



W1-032
20A switch with neon

Every space is elaborately decorated.



W1-033
45A switch with neon




W1-034
TV socket



W1-035
double TV socket

W1-036
computer socket



W1-037
tel socket



W1-038
satellite




W1-039
satellite+TV



W1-040
satellite+tel



W1-041
double satellite



W1-042
tv+tel socket

W1-043
TV+computer socket



W1-044
tel+computer socket

W1-045
double tel


W1-046
double computer socket



W1-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



W1-048
one gang switch+dimmer



W1-049
blank plate (3*3)



W1-050
blank plate(3*6)



W1-051
2* MF switch socket w/without neon

W1-052
2*MF switch socket+2USB
w/without neon

W1-053
2*MF switch socket +TypeA+C

W1-054
2*13A switch socket w/without neon
(single pole)

W1-055
2*13A switch socket w/without neon
(double pole)

W1-056
2*13A switch socket+2USB
w/without neon

W1-057
2*13A switch socket +TypeA+C

W1-058
45A switch with neon(3*6)

W1-059
cooker unit




W2
SERIES


Pure and Elegant Frameless Aesthetics

QUINTAL HOME
IMPROVE YOUR LIFE

W3
SERIES



W5
SERIES



W3

PC brushed panel
Iron bracket +PC bottom+Copper inside part



W3-001
1gang 1way switch 16A

W3-002
1gang 2way switch 16A



W3-003
2gang 1way switch 16A

W3-004
2gang 2way switch 16A



W3-005
3gang 1way switch 16A

W3-006
3gang 2way switch 16A



W3-007
4gang1way switch 16A

W3-008
4gang 2way switch 16A



W3-009
doorbell switch



W3-010
1 gang 1way switch and 2 pin socket

W3-011
1 gang 2way switch and 2 pin socket



W3-012
1gang 1way switch and 2gang 2pin socket

W3-012-1
1gang 2way switch and 2gang 2pin socket



W3-013
2gang 1way switch and 2gang 2pin socket

W3-013-1
2gang 2way switch and 2gang 2pin socket



W3-014
13A socket



W3-015
5Pin MF socket



W3-016
MF switch socket
w/without neon



W3-017
15A switch socket
w/without neon



W3-018
13A switch socket
w/without neon



W3-019
5 pin MF switch socket
w/without neon



W3-020
MF switch socket
w/without neon



W3-021
15A switch socket
w/without neon



W3-022
13A switch socket
w/without neon



W3-023
5 pin MF switch socket
w/without neon



W3-024
MF switch socket+2USB
w/without neon



W3-025
MF switch socket+TypeA+C
w/without neon



W3-026
13A switch socket+2USB
w/without neon(single pole)

W3-027
13A switch socket+2USB
w/without neon(double pole)



W3-028
13A switch socket+TypeA+C
w/without neon(single pole)

W3-029
13A switch socket+TypeA+C
w/without neon(double pole)



W3-030
European socket



W3-031
French socket



W3-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



W3-033
45A switch with neon



W3-034
TV socket



W3-035
double TV socket

W3-036
computer socket



W3-037
tel socket



W3-038
satellite



W3-039
satellite+TV



W3-040
satellite+tel



W3-041
double satellite



W3-042
tv+tel socket

W3-043
TV+computer socket



W3-044
tel+computer socket

W3-045
double tel

W3-046
double computer socket



W3-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



W3-048
one gang switch+dimmer



W3-049
blank plate (3*3)



W3-050
blank plate(3*6)



W3-051
2* MF switch socket w/without neon

W3-052
2*MF switch socket+2USB
w/without neon

W3-053
2*MF switch socket +TypeA+C

W3-054
2*13A switch socket w/without neon
(single pole)

W3-055
2*13A switch socket w/without neon
(double pole)

W3-056
2*13A switch socket+2USB
w/without neon

W3-057
2*13A switch socket +TypeA+C

W3-058
45A switch with neon(3*6)

W3-059
cooker unit

WEDO Electrical

W4

SERIES

QUINTAL HOME

IMPROVE YOUR LIFE



The atmospheric pattern is exquisitely carved.
Create a wonderful living life.



W4

PC panel with acrylic decoration
Iron bracket +PC bottom+Copper inside part



W4-001
1gang 1way switch 16A

W4-002
1gang 2way switch 16A



W4-003
2gang 1way switch 16A

W4-004
2gang 2way switch 16A



W4-005
3gang 1way switch 16A

W4-006
3gang 2way switch 16A



W4-007
4gang1way switch 16A

W4-008
4gang 2way switch 16A



W4-009
doorbell switch



W4-010
1 gang 1way switch and 2 pin socket

W4-011
1 gang 2way switch and 2 pin socket



W4-012
1gang 1way switch and 2gang 2pin socket

W4-012-1
1gang 2way switch and 2gang 2pin socket



W4-013
2gang 1way switch and 2gang 2pin socket

W4-013-1
2gang 2way switch and 2gang 2pin socket



W4-014
13A socket



W4-015
5Pin MF socket

W4-016
MF switch socket
w/without neon

W4-017
15A switch socket
w/without neon

W4-018
13A switch socket
w/without neon

W4-019
5 pin MF switch socket
w/without neon

W4-020
MF switch socket
w/without neon



W4-021
15A switch socket
w/without neon



W4-022
13A switch socket
w/without neon



W4-023
5 pin MF switch socket
w/without neon



W4-024
MF switch socket+2USB
w/without neon



W4-025
MF switch socket+TypeA+C
w/without neon



W4-026
13A switch socket+2USB
w/without neon(single pole)

W4-027
13A switch socket+2USB
w/without neon(double pole)



W4-028
13A switch socket+TypeA+C
w/without neon(single pole)

W4-029
13A switch socket+TypeA+C
w/without neon(double pole)



W4-030
European socket



W4-031
French socket



W4-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



W4-033
45A switch with neon



W4-034
TV socket



W4-035
double TV socket

W4-036
computer socket



W4-037
tel socket



W4-038
satellite



W4-039
satellite+TV



W4-040
satellite+tel



W4-041
double satellite



W4-042
tv+tel socket

W4-043
TV+computer socket



W4-044
tel+computer socket

W4-045
double tel

W4-046
double computer socket

W4-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W

W4-048
one gang switch+dimmer

W4-049
blank plate (3*3)



W4-050
blank plate(3*6)



W4-051
2* MF switch socket w/without neon

W4-052
2*MF switch socket+2USB
w/without neon

W4-053
2*MF switch socket +TypeA+C

W4-054
2*13A switch socket w/without neon
(single pole)

W4-055
2*13A switch socket w/without neon
(double pole)

W4-056
2*13A switch socket+2USB
w/without neon

W4-057
2*13A switch socket +TypeA+C


W4-058
45A switch with neon(3*6)

W4-059
cooker unit



W6
SERIES

QUINTAL HOME
IMPROVE YOUR LIFE



The atmospheric pattern is exquisitely carved.
Create a wonderful living life.



W6

Big glass/acrylic panel Iron bracket+Copper inside part



W9-001
1gang 1way switch 16A

W9-002
1gang 2way switch 16A



W9-003
2gang 1way switch 16A

W9-004
2gang 2way switch 16A



W9-005
3gang 1way switch 16A

W9-006
3gang 2way switch 16A



W9-007
4gang1way switch 16A

W9-008
4gang 2way switch 16A



W9-009
doorbell switch



W9-010
1 gang 1way switch and 2 pin socket

W9-011
1 gang 2way switch and 2 pin socket



W9-012
1gang 1way switch and 2gang 2pin socket

W9-012-1
1gang 2way switch and 2gang 2pin socket



W9-013
2gang 1way switch and 2gang 2pin socket

W9-013-1
2gang 2way switch and 2gang 2pin socket



W9-014
13A socket



W9-015
5Pin MF socket

W9-016
MF switch socket
w/without neon

W9-017
15A switch socket
w/without neon

W9-018
13A switch socket
w/without neon

W9-019
5 pin MF switch socket
w/without neon

W9-020
MF switch socket
w/without neon



W9-021
15A switch socket
w/without neon



W9-022
13A switch socket
w/without neon



W9-023
5 pin MF switch socket
w/without neon



W9-024
MF switch socket+2USB
w/without neon



W9-025
MF switch socket+TypeA+C
w/without neon



W9-026
13A switch socket+2USB
w/without neon(single pole)

W9-027
13A switch socket+2USB
w/without neon(double pole)



W9-028
13A switch socket+TypeA+C
w/without neon(single pole)

W9-029
13A switch socket+TypeA+C
w/without neon(double pole)



W9-030
European socket



W9-031
French socket



W9-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



W9-033
45A switch with neon



W9-034
TV socket



W9-035
double TV socket

W9-036
computer socket



W9-037
tel socket



W9-038
satellite



W9-039
satellite+TV



W9-040
satellite+tel



W9-041
double satellite



W9-042
tv+tel socket

W9-043
TV+computer socket



W9-044
tel+computer socket

W9-045
double tel

W9-046
double computer socket

W9-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W

W9-048
one gang switch+dimmer

W9-049
blank plate (3*3)



W9-050
blank plate(3*6)



W9-051
2* MF switch socket w/without neon

W9-052
2*MF switch socket+2USB
w/without neon

W9-053
2*MF switch socket +TypeA+C

W9-054
2*13A switch socket w/without neon
(single pole)

W9-055
2*13A switch socket w/without neon
(double pole)

W9-056
2*13A switch socket+2USB
w/without neon

W9-057
2*13A switch socket +TypeA+C

W9-058
45A switch with neon(3*6)

W9-059
cooker unit

W6
SERIES





W6

PC panel with chrome/painting
Iron bracket +PC bottom+Copper inside part



W6-001
1gang 1way switch 16A

W6-002
1gang 2way switch 16A



W6-003
2gang 1way switch 16A

W6-004
2gang 2way switch 16A



W6-005
3gang 1way switch 16A

W6-006
3gang 2way switch 16A



W6-007
4gang1way switch 16A

W6-008
4gang 2way switch 16A



W6-009
doorbell switch



W6-010
1 gang 1way switch and
2 pin socket

W6-011
1 gang 2way switch and 2
pin socket



W6-012
1gang 1way switch and
2gang 2pin socket

W6-012-1
1gang 2way switch and
2gang 2pin socket



W6-013
2gang 1way switch and
2gang 2pin socket

W6-013-1
2gang 2way switch and
2gang 2pin socket



W6-014
13A socket



W6-015
5Pin MF socket



W6-016
MF switch socket
w/without neon



W6-017
15A switch socket
w/without neon



W6-018
13A switch socket
w/without neon



W6-019
5 pin MF switch socket
w/without neon



W6-020
MF switch socket
w/without neon



W6-021
15A switch socket
w/without neon



W6-022
13A switch socket
w/without neon



W6-023
5 pin MF switch socket
w/without neon



W6-024
MF switch socket+2USB
w/without neon



W6-025
MF switch socket+TypeA+C
w/without neon



W6-026
13A switch socket+2USB
w/without neon(single pole)

W6-027
13A switch socket+2USB
w/without neon(double pole)



W6-028
13A switch socket+TypeA+C
w/without neon(single pole)

W6-029
13A switch socket+TypeA+C
w/without neon(double pole)



W6-030
European socket



W6-031
French socket



W6-032
20A switch with neon

Every space is elaborately decorated.



W6-033
45A switch with neon



W6-034
TV socket



W6-035
double TV socket

W6-036
computer socket



W6-037
tel socket



W6-038
satellite



W6-039
satellite+TV



W6-040
satellite+tel



W6-041
double satellite



W6-042
tv+tel socket

W6-043
TV+computer socket



W6-044
tel+computer socket

W6-045
double tel

W6-046
double computer socket




W6-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



W6-048
one gang switch+dimmer



W6-049
blank plate (3*3)



W6-050
blank plate(3*6)



W6-051
2* MF switch socket w/without neon

W6-052
2*MF switch socket+2USB
w/without neon

W6-053
2*MF switch socket +TypeA+C

W6-054
2*13A switch socket w/without neon
(single pole)

W6-055
2*13A switch socket w/without neon
(double pole)

W6-056
2*13A switch socket+2USB
w/without neon

W6-057
2*13A switch socket +TypeA+C

W6-058
45A switch with neon(3*6)

W6-059
cooker unit



The lighting switch is charming and classic
Elegant and luxurious,which transform the houses and rooms into gorgeous





W8

Big PC panel white/painting Iron bracket +PC bottom+Copper inside part

W8-001
1gang 1way switch 16A

W8-002
1gang 2way switch 16A



W8-003
2gang 1way switch 16A

W8-004
2gang 2way switch 16A



W8-005
3gang 1way switch 16A

W8-006
3gang 2way switch 16A




W8-007
4gang1way switch 16A

W8-008
4gang 2way switch 16A




W8-009
doorbell switch




W8-010
1 gang 1way switch and 2 pin socket

W8-011
1 gang 2way switch and 2 pin socket



W8-012
1gang 1way switch and 2gang 2pin socket

W8-012-1
1gang 2way switch and 2gang 2pin socket



W8-013
2gang 1way switch and 2gang 2pin socket

W8-013-1
2gang 2way switch and 2gang 2pin socket



W8-014
13A socket



W8-015
5Pin MF socket



W8-016
MF switch socket
w/without neon



W8-017
15A switch socket
w/without neon




W8-018
13A switch socket
w/without neon




W8-019
5 pin MF switch socket
w/without neon



W8-020
MF switch socket
w/without neon



W8-021
15A switch socket
w/without neon



W8-022
13A switch socket
w/without neon




W8-023
5 pin MF switch socket
w/without neon



W8-024
MF switch socket+2USB
w/without neon




W8-025
MF switch socket+TypeA+C
w/without neon



W8-026
13A switch socket+2USB
w/without neon(single pole)

W8-027
13A switch socket+2USB
w/without neon(double pole)



W8-028
13A switch socket+TypeA+C
w/without neon(single pole)

W8-029
13A switch socket+TypeA+C
w/without neon(double pole)



W8-030
European socket



W8-031
French socket



W8-032
20A switch with neon



W8-033
45A switch with neon



W8-034
TV socket



W8-035
double TV socket


W8-036
computer socket



W8-037
tel socket



W8-038
satellite



W8-039
satellite+TV



W8-040
satellite+tel



W8-041
double satellite



W8-042
tv+tel socket

W8-043
TV+computer socket




W8-044
tel+computer socket

W8-045
double tel

W8-046
double computer socket




W8-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



W8-048
one gang switch+dimmer

W8-049
blank plate (3*3)

W8-050
blank plate(3*6)



W8-051
2* MF switch socket w/without neon

W8-052
2*MF switch socket+2USB
w/without neon

W8-053
2*MF switch socket +TypeA+C

W8-054
2*13A switch socket w/without neon (single pole)

W8-055
2*13A switch socket w/without neon (double pole)

W8-056
2*13A switch socket+2USB
w/without neon

W8-057
2*13A switch socket +TypeA+C

W8-058
45A switch with neon(3*6)

W8-059
cooker unit



W9
SERIES





W9 | Big PC panel white/painting Iron bracket +PC bottom+Copper inside part



W9-001
1gang 1way switch 16A

W9-002
1gang 2way switch 16A



W9-003
2gang 1way switch 16A

W9-004
2gang 2way switch 16A



W9-005
3gang 1way switch 16A

W9-006
3gang 2way switch 16A



W9-007
4gang1way switch 16A

W9-008
4gang 2way switch 16A



W9-009
doorbell switch



W9-010
1 gang 1way switch and 2 pin socket

W9-011
1 gang 2way switch and 2 pin socket



W9-012
1gang 1way switch and 2gang 2pin socket

W9-012-1
1gang 2way switch and 2gang 2pin socket



W9-013
2gang 1way switch and 2gang 2pin socket

W9-013-1
2gang 2way switch and 2gang 2pin socket



W9-014
13A socket



W9-015
5Pin MF socket



W9-016
MF switch socket
w/without neon



W9-017
15A switch socket
w/without neon



W9-018
13A switch socket
w/without neon



W9-019
5 pin MF switch socket
w/without neon



W9-020
MF switch socket
w/without neon



W9-021
15A switch socket
w/without neon



W9-022
13A switch socket
w/without neon



W9-023
5 pin MF switch socket
w/without neon



W9-024
MF switch socket+2USB
w/without neon



W9-025
MF switch socket+TypeA+C
w/without neon



W9-026
13A switch socket+2USB
w/without neon(single pole)

W9-027
13A switch socket+2USB
w/without neon(double pole)



W9-028
13A switch socket+TypeA+C
w/without neon(single pole)

W9-029
13A switch socket+TypeA+C
w/without neon(double pole)



W9-030
European socket



W9-031
French socket



W9-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



W9-033
45A switch with neon



W9-034
TV socket



W9-035
double TV socket

W9-036
computer socket



W9-037
tel socket



W9-038
satellite



W9-039
satellite+TV



W9-040
satellite+tel



W9-041
double satellite



W9-042
tv+tel socket

W9-043
TV+computer socket



W9-044
tel+computer socket

W9-045
double tel

W9-046
double computer socket



W9-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



W9-048
one gang switch+dimmer



W9-049
blank plate (3*3)



W9-050
blank plate(3*6)



W9-051
2* MF switch socket w/without neon

W9-052
2*MF switch socket+2USB
w/without neon

W9-053
2*MF switch socket +TypeA+C

W9-054
2*13A switch socket w/without neon
(single pole)

W9-055
2*13A switch socket w/without neon
(double pole)

W9-056
2*13A switch socket+2USB
w/without neon

W9-057
2*13A switch socket +TypeA+C

W9-058
45A switch with neon(3*6)

W9-059
cooker unit



QUINTAL HOME
IMPROVE YOUR LIFE



W10
SERIES

W10

Big PC panel white/painting Iron bracket +PC bottom+Copper inside part



W10-001
1gang 1way switch 16A

W10-002
1gang 2way switch 16A



W10-003
2gang 1way switch 16A

W10-004
2gang 2way switch 16A



W10-005
3gang 1way switch 16A

W10-006
3gang 2way switch 16A



W10-007
4gang1way switch 16A

W10-008
4gang 2way switch 16A



W10-009
doorbell switch



W10-010
1 gang 1way switch and 2 pin socket

W10-011
1 gang 2way switch and 2 pin socket



W10-012
1gang 1way switch and 2gang 2pin socket

W10-012-1
1gang 2way switch and 2gang 2pin socket



W10-013
2gang 1way switch and 2gang 2pin socket

W10-013-1
2gang 2way switch and 2gang 2pin socket



W10-014
13A socket



W10-015
5Pin MF socket



W10-016
MF switch socket
w/without neon



W10-017
15A switch socket
w/without neon



W10-018
13A switch socket
w/without neon



W10-019
5 pin MF switch socket
w/without neon



W10-020
MF switch socket
w/without neon



W10-021
15A switch socket
w/without neon



W10-022
13A switch socket
w/without neon



W10-023
5 pin MF switch socket
w/without neon



W10-024
MF switch socket+2USB
w/without neon



W10-025
MF switch socket+TypeA+C
w/without neon



W10-026
13A switch socket+2USB
w/without neon(single pole)

W10-027
13A switch socket+2USB
w/without neon(double pole)



W10-028
13A switch socket+TypeA+C
w/without neon(single pole)

W10-029
13A switch socket+TypeA+C
w/without neon(double pole)



W10-030
European socket



W10-031
French socket



W10-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



W10-033
45A switch with neon



W10-034
TV socket



W10-035
double TV socket

W10-036
computer socket



W10-037
tel socket



W10-038
satellite



W10-039
satellite+TV



W10-040
satellite+tel



W10-041
double satellite



W10-042
tv+tel socket

W10-043
TV+computer socket



W10-044
tel+computer socket

W10-045
double tel

W10-046
double computer socket



W10-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



W10-048
one gang switch+dimmer



W10-049
blank plate (3*3)



W10-050
blank plate(3*6)



W10-051
2* MF switch socket w/without neon

W10-052
2*MF switch socket+2USB
w/without neon

W10-053
2*MF switch socket +TypeA+C

W10-054
2*13A switch socket w/without neon
(single pole)

W10-055
2*13A switch socket w/without neon
(double pole)

W10-056
2*13A switch socket+2USB
w/without neon

W10-057
2*13A switch socket +TypeA+C

W10-058
45A switch with neon(3*6)

W10-059
cooker unit

QUINTAL HOME
IMPROVE YOUR LIFE

RESET TYPE
SERIES





C1
SERIES

Simply but elegant.
The combination between golden chrome plating and big panel without monotonous surface



White | Gold | Grey | Brushed gold | Brushed grey



C1

PC panel with chrome/painting
Iron bracket +PC bottom+Copper inside part



C1-001
1gang 1way switch 16A

C1-002
1gang 2way switch 16A



C1-003
2gang 1way switch 16A

C1-004
2gang 2way switch 16A



C1-005
3gang 1way switch 16A

C1-006
3gang 2way switch 16A



C1-007
4gang1way switch 16A

C1-008
4gang 2way switch 16A



C1-009
doorbell switch



C1-010
1 gang 1way switch and
2 pin socket

C1-011
1 gang 2way switch and 2
pin socket



C1-012
1gang 1way switch and
2gang 2pin socket

C1-012-1
1gang 2way switch and
2gang 2pin socket



C1-013
2gang 1way switch and
2gang 2pin socket

C1-013-1
2gang 2way switch and
2gang 2pin socket



C1-014
13A socket



C1-015
5Pin MF socket



C1-016
MF switch socket
w/without neon



C1-017
15A switch socket
w/without neon



C1-018
13A switch socket
w/without neon



C1-019
5 pin MF switch socket
w/without neon



C1-020
MF switch socket
w/without neon



C1-021
15A switch socket
w/without neon



C1-022
13A switch socket
w/without neon



C1-023
5 pin MF switch socket
w/without neon



C1-024
MF switch socket+2USB
w/without neon



C1-025
MF switch socket+TypeA+C
w/without neon



C1-026
13A switch socket+2USB
w/without neon(single pole)

C1-027
13A switch socket+2USB
w/without neon(double pole)



C1-028
13A switch socket+TypeA+C
w/without neon(single pole)

C1-029
13A switch socket+TypeA+C
w/without neon(double pole)



C1-030
European socket



C1-031
French socket



C1-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



C1-033
45A switch with neon



C1-034
TV socket



C1-035
double TV socket

C1-036
computer socket



C1-037
tel socket



C1-038
satellite



C1-039
satellite+TV



C1-040
satellite+tel



C1-041
double satellite



C1-042
tv+tel socket

C1-043
TV+computer socket



C1-044
tel+computer socket

C1-045
double tel

C1-046
double computer socket



C1-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



C1-048
one gang switch+dimmer



C1-049
blank plate (3*3)



C1-050
blank plate(3*6)



C1-051
2* MF switch socket w/without neon

C1-052
2*MF switch socket+2USB
w/without neon

C1-053
2*MF switch socket +TypeA+C

C1-054
2*13A switch socket w/without neon
(single pole)

C1-055
2*13A switch socket w/without neon
(double pole)

C1-056
2*13A switch socket+2USB
w/without neon

C1-057
2*13A switch socket +TypeA+C

C1-058
45A switch with neon(3*6)

C1-059
cooker unit







C1
SERIES

Acrylic colorful pattern craft panel，it shows the aesthetics and the embedded valu of classic

C1

Acrylic panel with chrome/painting
Iron bracket +PC bottom+Copper inside part



C1-001
1gang 1way switch 16A

C1-002
1gang 2way switch 16A



C1-003
2gang 1way switch 16A

C1-004
2gang 2way switch 16A



C1-005
3gang 1way switch 16A

C1-006
3gang 2way switch 16A



C1-007
4gang1way switch 16A

C1-008
4gang 2way switch 16A



C1-009
doorbell switch



C1-010
1 gang 1way switch and
2 pin socket

C1-011
1 gang 2way switch and 2
pin socket



C1-012
1gang 1way switch and
2gang 2pin socket

C1-012-1
1gang 2way switch and
2gang 2pin socket



C1-013
2gang 1way switch and
2gang 2pin socket

C1-013-1
2gang 2way switch and
2gang 2pin socket



C1-014
13A socket



C1-015
5Pin MF socket



C1-016
MF switch socket
w/without neon



C1-017
15A switch socket
w/without neon



C1-018
13A switch socket
w/without neon



C1-019
5 pin MF switch socket
w/without neon



C1-020
MF switch socket
w/without neon



C1-021
15A switch socket
w/without neon



C1-022
13A switch socket
w/without neon



C1-023
5 pin MF switch socket
w/without neon



C1-024
MF switch socket+2USB
w/without neon



C1-025
MF switch socket+TypeA+C
w/without neon



C1-026
13A switch socket+2USB
w/without neon(single pole)

C1-027
13A switch socket+2USB
w/without neon(double pole)



C1-028
13A switch socket+TypeA+C
w/without neon(single pole)

C1-029
13A switch socket+TypeA+C
w/without neon(double pole)



C1-030
European socket



C1-031
French socket



C1-032
20A switch with neon



C1-033
45A switch with neon



C1-034
TV socket



C1-035
double TV socket

C1-036
computer socket



C1-037
tel socket



C1-038
satellite



C1-039
satellite+TV



C1-040
satellite+tel



C1-041
double satellite



C1-042
tv+tel socket

C1-043
TV+computer socket



C1-044
tel+computer socket

C1-045
double tel

C1-046
double computer socket



C1-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



C1-048
one gang switch+dimmer



C1-049
blank plate (3*3)



C1-050
blank plate(3*6)



C1-051
2* MF switch socket w/without neon

C1-052
2*MF switch socket+2USB
w/without neon

C1-053
2*MF switch socket +TypeA+C

C1-054
2*13A switch socket w/without neon
(single pole)

C1-055
2*13A switch socket w/without neon
(double pole)

C1-056
2*13A switch socket+2USB
w/without neon

C1-057
2*13A switch socket +TypeA+C

C1-058
45A switch with neon(3*6)

C1-059
cooker unit



C2
SERIES

QUINTAL HOME
IMPROVE YOUR LIFE



C3
SERIES

C2

PC panel with chrome/painting
Iron bracket +PC bottom+Copper inside part



C2-001
1gang 1way switch 16A

C2-002
1gang 2way switch 16A



C2-003
2gang 1way switch 16A

C2-004
2gang 2way switch 16A



C2-005
3gang 1way switch 16A

C2-006
3gang 2way switch 16A



C2-007
4gang1way switch 16A

C2-008
4gang 2way switch 16A



C2-009
doorbell switch



C2-010
1 gang 1way switch and
2 pin socket

C2-011
1 gang 2way switch and 2
pin socket



C2-012
1gang 1way switch and
2gang 2pin socket

C2-012-1
1gang 2way switch and
2gang 2pin socket



C2-013
2gang 1way switch and
2gang 2pin socket

C2-013-1
2gang 2way switch and
2gang 2pin socket



C2-014
13A socket



C2-015
5Pin MF socket

C2-016
MF switch socket
w/without neon

C2-017
15A switch socket
w/without neon

C2-018
13A switch socket
w/without neon

C2-019
5 pin MF switch socket
w/without neon

C2-020
MF switch socket
w/without neon



C2-021
15A switch socket
w/without neon



C2-022
13A switch socket
w/without neon



C2-023
5 pin MF switch socket
w/without neon



C2-024
MF switch socket+2USB
w/without neon



C2-025
MF switch socket+TypeA+C
w/without neon



C2-026
13A switch socket+2USB
w/without neon(single pole)

C2-027
13A switch socket+2USB
w/without neon(double pole)



C2-028
13A switch socket+TypeA+C
w/without neon(single pole)

C2-029
13A switch socket+TypeA+C
w/without neon(double pole)



C2-030
European socket



C2-031
French socket



C2-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



C2-033
45A switch with neon



C2-034
TV socket



C2-035
double TV socket

C2-036
computer socket



C2-037
tel socket



C2-038
satellite



C2-039
satellite+TV



C2-040
satellite+tel



C2-041
double satellite



C2-042
tv+tel socket

C2-043
TV+computer socket



C2-044
tel+computer socket

C2-045
double tel

C2-046
double computer socket

C2-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W

C2-048
one gang switch+dimmer

C2-049
blank plate (3*3)



C2-050
blank plate(3*6)



C2-051
2* MF switch socket w/without neon

C2-052
2*MF switch socket+2USB
w/without neon

C2-053
2*MF switch socket +TypeA+C

C2-054
2*13A switch socket w/without neon
(single pole)

C2-055
2*13A switch socket w/without neon
(double pole)

C2-056
2*13A switch socket+2USB
w/without neon


C2-057
2*13A switch socket +TypeA+C

C2-058
45A switch with neon(3*6)

C2-059
cooker unit

QUINTAL HOME
IMPROVE YOUR LIFE

C7
SERIES



Extraordinary modern design, classical art form and appearance,
meticulous surface, we pay more attention to detail quality,
continuation of historical classics, pursuit the perfect of noble choice.

C7

PC panel with painting
Iron bracket +PC bottom+Copper inside part



C7-001
1gang 1way switch 16A

C7-002
1gang 2way switch 16A



C7-003
2gang 1way switch 16A

C7-004
2gang 2way switch 16A



C7-005
3gang 1way switch 16A

C7-006
3gang 2way switch 16A



C7-007
4gang1way switch 16A

C7-008
4gang 2way switch 16A



C7-009
doorbell switch



C7-010
1 gang 1way switch and
2 pin socket

C7-011
1 gang 2way switch and 2
pin socket



C7-012
1gang 1way switch and
2gang 2pin socket

C7-012-1
1gang 2way switch and
2gang 2pin socket



C7-013
2gang 1way switch and
2gang 2pin socket

C7-013-1
2gang 2way switch and
2gang 2pin socket



C7-014
13A socket



C7-015
5Pin MF socket



C7-016
MF switch socket
w/without neon



C7-017
15A switch socket
w/without neon



C7-018
13A switch socket
w/without neon



C7-019
5 pin MF switch socket
w/without neon



C7-020
MF switch socket
w/without neon



C7-021
15A switch socket
w/without neon



C7-022
13A switch socket
w/without neon



C7-023
5 pin MF switch socket
w/without neon



C7-024
MF switch socket+2USB
w/without neon



C7-025
MF switch socket+TypeA+C
w/without neon



C7-026
13A switch socket+2USB
w/without neon(single pole)

C7-027
13A switch socket+2USB
w/without neon(double pole)



C7-028
13A switch socket+TypeA+C
w/without neon(single pole)

C7-029
13A switch socket+TypeA+C
w/without neon(double pole)



C7-030
European socket



C7-031
French socket



C7-032
20A switch with neon


QUINTAL HOME
IMPROVE YOUR LIFE



C7-033
45A switch with neon



C7-034
TV socket



C7-035
double TV socket

C7-036
computer socket



C7-037
tel socket



C7-038
satellite



C7-039
satellite+TV



C7-040
satellite+tel



C7-041
double satellite



C7-042
tv+tel socket

C7-043
TV+computer socket



C7-044
tel+computer socket

C7-045
double tel

C7-046
double computer socket




C7-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



C7-048
one gang switch+dimmer



C7-049
blank plate (3*3)



C7-050
blank plate(3*6)



C7-051
2* MF switch socket w/without neon

C7-052
2*MF switch socket+2USB
w/without neon

C7-053
2*MF switch socket +TypeA+C

C7-054
2*13A switch socket w/without neon
(single pole)

C7-055
2*13A switch socket w/without neon
(double pole)

C7-056
2*13A switch socket+2USB
w/without neon

C7-057
2*13A switch socket +TypeA+C

C7-058
45A switch with neon(3*6)

C7-059
cooker unit



White



Gold



Grey



Black

QUINTAL HOME
IMPROVE YOUR LIFE



C8
SERIES



QUINTAL HOME
IMPROVE YOUR LIFE

Wood Grain Series
Variable variety of patterns, free choice
the background is selected wood grain
pattern，the periphery is an antique chrome frame

C8
SERIES


Walnut


Red oak


Gold(Acrylic)


White(Acrylic)

C8

Wooden panel Iron bracket +PC bottom+Copper inside part



C8-001
1gang 1way switch 16A

C8-002
1gang 2way switch 16A



C8-003
2gang 1way switch 16A

C8-004
2gang 2way switch 16A



C8-005
3gang 1way switch 16A

C8-006
3gang 2way switch 16A



C8-007
4gang1way switch 16A

C8-008
4gang 2way switch 16A



C8-009
doorbell switch



C8-010
1 gang 1way switch and
2 pin socket

C8-011
1 gang 2way switch and 2
pin socket



C8-012
1gang 1way switch and
2gang 2pin socket

C8-012-1
1gang 2way switch and
2gang 2pin socket



C8-013
2gang 1way switch and
2gang 2pin socket

C8-013-1
2gang 2way switch and
2gang 2pin socket



C8-014
13A socket



C8-015
5Pin MF socket



C8-016
MF switch socket
w/without neon



C8-017
15A switch socket
w/without neon



C8-018
13A switch socket
w/without neon



C8-019
5 pin MF switch socket
w/without neon



C8-020
MF switch socket
w/without neon



C8-021
15A switch socket
w/without neon



C8-022
13A switch socket
w/without neon



C8-023
5 pin MF switch socket
w/without neon



C8-024
MF switch socket+2USB
w/without neon



C8-025
MF switch socket+TypeA+C
w/without neon



C8-026
13A switch socket+2USB
w/without neon(single pole)

C8-027
13A switch socket+2USB
w/without neon(double pole)



C8-028
13A switch socket+TypeA+C
w/without neon(single pole)

C8-029
13A switch socket+TypeA+C
w/without neon(double pole)



C8-030
European socket



C8-031
French socket



C8-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



C8-033
45A switch with neon



C8-034
TV socket



C8-035
double TV socket

C8-036
computer socket



C8-037
tel socket



C8-038
satellite



C8-039
satellite+TV



C8-040
satellite+tel



C8-041
double satellite



C8-042
tv+tel socket

C8-043
TV+computer socket



C8-044
tel+computer socket

C8-045
double tel

C8-046
double computer socket



C8-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W



C8-048
one gang switch+dimmer



C8-049
blank plate (3*3)



C8-050
blank plate(3*6)



C8-051
2* MF switch socket w/without neon

C8-052
2*MF switch socket+2USB
w/without neon

C8-053
2*MF switch socket +TypeA+C

C8-054
2*13A switch socket w/without neon
(single pole)


C8-055
2*13A switch socket w/without neon
(double pole)

C8-056
2*13A switch socket+2USB
w/without neon

C8-057
2*13A switch socket +TypeA+C

C8-058
45A switch with neon(3*6)

C8-059
cooker unit



Follow the European royal style to bring a cool touch with champagne decoration

3D Gold





C9



C9-001
1gang 1way switch 16A

C9-002
1gang 2way switch 16A



C9-003
2gang 1way switch 16A

C9-004
2gang 2way switch 16A



C9-005
3gang 1way switch 16A

C9-006
3gang 2way switch 16A



C9-007
4gang1way switch 16A

C9-008
4gang 2way switch 16A



C9-009
doorbell switch



C9-010
1 gang 1way switch and
2 pin socket

C9-011
1 gang 2way switch and 2
pin socket



C9-012
1gang 1way switch and
2gang 2pin socket

C9-012-1
1gang 2way switch and
2gang 2pin socket



C9-013
2gang 1way switch and
2gang 2pin socket

C9-013-1
2gang 2way switch and
2gang 2pin socket



C9-014
13A socket



C9-015
5Pin MF socket

C9-016
MF switch socket
w/without neon

C9-017
15A switch socket
w/without neon

C9-018
13A switch socket
w/without neon

C9-019
5 pin MF switch socket
w/without neon

C9-020
MF switch socket
w/without neon



C9-021
15A switch socket
w/without neon



C9-022
13A switch socket
w/without neon



C9-023
5 pin MF switch socket
w/without neon



C9-024
MF switch socket+2USB
w/without neon



C9-025
MF switch socket+TypeA+C
w/without neon



C9-026
13A switch socket+2USB
w/without neon(single pole)

C9-027
13A switch socket+2USB
w/without neon(double pole)



C9-028
13A switch socket+TypeA+C
w/without neon(single pole)

C9-029
13A switch socket+TypeA+C
w/without neon(double pole)



C9-030
European socket



C9-031
French socket



C9-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE

Every space is elaborately decorated.



C9-033
45A switch with neon



C9-034
TV socket



C9-035
double TV socket

C9-036
computer socket



C9-037
tel socket



C9-038
satellite



C9-039
satellite+TV



C9-040
satellite+tel



C9-041
double satellite



C9-042
tv+tel socket

C9-043
TV+computer socket



C9-044
tel+computer socket

C9-045
double tel

C9-046
double computer socket

C9-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W

C9-048
one gang switch+dimmer

C9-049
blank plate (3*3)



C9-050
blank plate(3*6)



C9-051
2* MF switch socket w/without neon

C9-052
2*MF switch socket+2USB
w/without neon

C9-053
2*MF switch socket +TypeA+C

C9-054
2*13A switch socket w/without neon
(single pole)

C9-055
2*13A switch socket w/without neon
(double pole)


C9-056
2*13A switch socket+2USB
w/without neon

C9-057
2*13A switch socket +TypeA+C

C9-058
45A switch with neon(3*6)

C9-059
cooker unit





M3
SERIES



White



Gold



Red oak



Grey



Walnut

M3

PC panel with painting
Iron bracket +PC bottom+Copper inside part



M3-001
1gang 1way switch 16A

M3-002
1gang 2way switch 16A



M3-003
2gang 1way switch 16A

M3-004
2gang 2way switch 16A



M3-005
3gang 1way switch 16A

M3-006
3gang 2way switch 16A



M3-007
4gang1way switch 16A

M3-008
4gang 2way switch 16A



M3-009
doorbell switch



M3-010
1 gang 1way switch and
2 pin socket

M3-011
1 gang 2way switch and 2
pin socket



M3-012
1gang 1way switch and
2gang 2pin socket

M3-012-1
1gang 2way switch and
2gang 2pin socket



M3-013
2gang 1way switch and
2gang 2pin socket

M3-013-1
2gang 2way switch and
2gang 2pin socket



M3-014
13A socket



M3-015
5Pin MF socket

M3-016
MF switch socket
w/without neon

M3-017
15A switch socket
w/without neon

M3-018
13A switch socket
w/without neon

M3-019
5 pin MF switch socket
w/without neon

M3-020
MF switch socket
w/without neon



M3-021
15A switch socket
w/without neon



M3-022
13A switch socket
w/without neon



M3-023
5 pin MF switch socket
w/without neon



M3-024
MF switch socket+2USB
w/without neon



M3-025
MF switch socket+TypeA+C
w/without neon



M3-026
13A switch socket+2USB
w/without neon(single pole)

M3-027
13A switch socket+2USB
w/without neon(double pole)



M3-028
13A switch socket+TypeA+C
w/without neon(single pole)

M3-029
13A switch socket+TypeA+C
w/without neon(double pole)



M3-030
European socket



M3-031
French socket



M3-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



M3-033
45A switch with neon



M3-034
TV socket



M3-035
double TV socket

M3-036
computer socket



M3-037
tel socket



M3-038
satellite



M3-039
satellite+TV



M3-040
satellite+tel



M3-041
double satellite



M3-042
tv+tel socket

M3-043
TV+computer socket



M3-044
tel+computer socket

M3-045
double tel

M3-046
double computer socket

M3-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W

M3-048
one gang switch+dimmer

M3-049
blank plate (3*3)

M3-050
blank plate(3*6)



M3-051
2* MF switch socket w/without neon



M3-052
2*MF switch socket+2USB
w/without neon




M3-053
2*MF switch socket +TypeA+C



M3-054
2*13A switch socket w/without neon
(single pole)


M3-055
2*13A switch socket w/without neon
(double pole)



M3-056
2*13A switch socket+2USB
w/without neon



M3-057
2*13A switch socket +TypeA+C



M3-058
45A switch with neon(3*6)



M3-059
cooker unit

Q2
SERIES



Q4
SERIES



The wonderful combination of cross-drawing and spray paint.
Enjoy quality life with chic and soft.



Q4
SERIES

Q4



Q4-001
1gang 1way switch 16A

Q4-002
1gang 2way switch 16A



Q4-003
2gang 1way switch 16A

Q4-004
2gang 2way switch 16A



Q4-005
3gang 1way switch 16A

Q4-006
3gang 2way switch 16A



Q4-007
4gang1way switch 16A

Q4-008
4gang 2way switch 16A



Q4-009
doorbell switch



Q4-010
1 gang 1way switch and
2 pin socket

Q4-011
1 gang 2way switch and 2
pin socket



Q4-012
1gang 1way switch and
2gang 2pin socket

Q4-012-1
1gang 2way switch and
2gang 2pin socket



Q4-013
2gang 1way switch and
2gang 2pin socket

Q4-013-1
2gang 2way switch and
2gang 2pin socket



Q4-014
13A socket



Q4-015
5Pin MF socket

Q4-016
MF switch socket
w/without neon

Q4-017
15A switch socket
w/without neon

Q4-018
13A switch socket
w/without neon

Q4-019
5 pin MF switch socket
w/without neon

Q4-020
MF switch socket
w/without neon



Q4-021
15A switch socket
w/without neon



Q4-022
13A switch socket
w/without neon



Q4-023
5 pin MF switch socket
w/without neon



Q4-024
MF switch socket+2USB
w/without neon



Q4-025
MF switch socket+TypeA+C
w/without neon



Q4-026
13A switch socket+2USB
w/without neon(single pole)

Q4-027
13A switch socket+2USB
w/without neon(double pole)



Q4-028
13A switch socket+TypeA+C
w/without neon(single pole)

Q4-029
13A switch socket+TypeA+C
w/without neon(double pole)



Q4-030
European socket



Q4-031
French socket



Q4-032
20A switch with neon

QUINTAL HOME
IMPROVE YOUR LIFE



Q4-033
45A switch with neon



Q4-034
TV socket



Q4-035
double TV socket

Q4-036
computer socket



Q4-037
tel socket



Q4-038
satellite



Q4-039
satellite+TV



Q4-040
satellite+tel



Q4-041
double satellite



Q4-042
tv+tel socket

Q4-043
TV+computer socket



Q4-044
tel+computer socket

Q4-045
double tel


Q4-046
double computer socket

Q4-047
fan dimmer with step 500W
light dimmer 1000W
light dimmer 1500W
light/fan dimmer 500W


Q4-048
one gang switch+dimmer

Q4-049
blank plate (3*3)


Q4-050
blank plate(3*6)




Q4-051
2* MF switch socket w/without neon



Q4-052
2*MF switch socket+2USB
w/without neon




Q4-053
2*MF switch socket +TypeA+C




Q4-054
2*13A switch socket w/without neon
(single pole)


Q4-055
2*13A switch socket w/without neon
(double pole)




Q4-056
2*13A switch socket+2USB
w/without neon



Q4-057
2*13A switch socket +TypeA+C



Q4-058
45A switch with neon(3*6)



Q4-059
cooker unit